

Neroform AG

Wankdorffeldstrasse 64
3014 **Bern**

Test report

Test-report No.: 2006/060510 Prüfer Neroform/Version 1

Subject of the test

To prove the effectiveness of the method of cleaning and disinfection of keyboards (computer, telephone) and equipment surfaces (mouse, telephone) used by Neroform AG, Bern.
Assessment and confirmation on the basis of practical tests.

Test procedure

Object: The aim is that, by cleaning and disinfection by wiping, the keyboard and equipment surface can be treated with defined cleaning and disinfection agents, so that the soiling and micro-organisms present (bacteria, yeasts and moulds) are reduced by more than 90%.

Material: Cleaning and disinfection agents:

- Nerodata (cleaning agent for keyboards)
- Nerolit (cleaning agent for equipment surfaces)
- Neroform (disinfectant for keyboards and surfaces)
- Various defined cloths

Procedure: different procedures are described for the keyboard and equipment surfaces

- Keyboard:
 - tip over, shake out, clean with a brush
 - moisten a cloth with Nerodata, wipe over the keys; then rub again with a second cloth
 - wet a clean cloth thoroughly with Neroform and wipe it over the keyboard
 - take a swab, then rub over with Neroform again
- Mouse and telephone:
 - wet a cloth with Nerolit, wipe over the surfaces, then rub over with a second cloth
 - wet a clean cloth thoroughly with Neroform and wipe it over the keyboard
 - take a swab, then rub over with Neroform again

Operators: trained staff

Inspection:

The hygienic-microbiological inspection was carried out at defined places by means of spread-plates (Rodac type, Caso-Agar with disinhibitor), before and after treatment of the test objects.

Warning: The test results refer exclusively to the samples taken and not to the whole batch, production run etc. This test report may only be reproduced as a whole. Test methods not falling within the accredited field are marked *. Terms and conditions of business can be requested.